KERN & Sohn GmbH
Ziegelei 1
72336 Balingen-Frommern
Germany

www.kern-sohn.com
+0049-[0]7433-9933-0
+0049-[0]7433-9933-149
info@kern-sohn.com

Operating instructions Precision Balance

KERN EWJ

Type TEWJ-A

Version 1.0

2025-06

en



TEWJ-A-BA-e-2510

en

KERN EWJ

Version 1.0 2025-06

Operating instructions Precision balance

Contents

1 Technical data 4

2 Declaration of conformity 5

3 Appliance overview 6

3.1 Components 6

3.2 Operating elements 7

3.2.1 Keyboard overview 7

3.2.2 Numerical input 8

3.2.3 Overview of displays 8

4 Basic Information (General) 10

4.1 Proper use 10

4.2 Improper Use 10

4.3 Warranty 10

4.4 Monitoring of Test Resources 11

5 Basic Safety Precautions 11

5.1 Pay attention to the instructions in the Operation Manual 11

5.1 Personnel training 11

6 Transport and storage 11

6.1 Testing upon acceptance 11

6.1 Packaging / return transport 11

7 Unpacking, Installation and Commissioning 12

7.1 Installation Site, Location of Use 12

7.2 Unpacking and checking 13

7.3 Assembling, Installation and Levelling 13

7.4 Mains connection 13

7.5 Rechargeable battery operation (Factory option) 14

7.5.1 Load rechargeable battery 14

7.6 Connection of peripheral devices 15

7.7 Initial Commissioning 15

7.8 Adjustment 15

7.8.1 Internal adjustment < CAL int > 16

8 Verification 17

9 Basic Operation 19
9.1 Turn on/off 19
9.2 Simple weighing 19
9.3 Zeroing 20
9.4 Taring 20
9.5 Switch-over weighing unit 21
10 Operating concept 23
11 Application <Weighing> 25
11.1 Application-specific settings 25
11.2 PRE-Tare 26
11.2.1 Take over the placed weight as PRE-TARE value 26
11.2.2 Enter the known tare weight numerically 27
11.3 Data-Hold function 28
11.4 Weighing Units 28
11.4.1 Setting weighing unit 28
11.4.2 Percent weighing by application unit <%> 29
12 Application <Counting> 30
12.1 Application-specific settings 30
12.2 Using the application 31
12.2.1 Piece counting 31
12.2.2 Target counting 34
13 Application < Checkweighing > 37
13.1 Application-specific settings 37
13.2 Using the application 38
13.2.1 Target weighing 38
13.2.2 Checkweighing 41
14 Menü 43
14.1 Navigation in the menu 43
14.2 Application menu 43
14.3 Setup menu 44
14.3.1 Overview < setup > 44
15 Servicing, maintenance, disposal 46
15.1 Cleaning 46
15.2 Servicing, maintenance 46
15.3 Disposal 46
16 Instant help for troubleshooting 47
17 Error messages 48

1 Technical data

KERN	EWJ 600-1M
Item number / type	TEWJ 600-1M-A
Readability (d)	0,1 g
Weighing range (max)	600 g
Reproducibility	0,1 g
Linearity	± 0,3 g
Settling time (typical)	2 s
Calibration value (e)	0,1 g
Calibration class	II
Minimum weight (min)	0,5 g
Smallest part weight when counting parts under laboratory conditions*	200 mg
Smallest part weight when counting parts under normal conditions**	2 g
Warm-up time	30 min
Weighing units	g
Air humidity	80 %
Permissible ambient temperature	15 °C ... 35 °C
Input voltage Device	12 V DC, 500 mA
Input voltage power supply unit	100 V - 240 V, 50 / 60 Hz
Battery operation (option)	Operating time 57 h (backlight off) Operating time 32 h (backlight on) Charging time approx. 6.5 h
Auto off (battery)	selectable 30 s; 1 / 2 / 5 / 30 / 60 min
Housing dimensions	220 x 340 x 180 mm
Weighing plate, stainless steel	Ø 120 mm
Net weight (kg)	3,2

*** Smallest part weight for piece counting - under lab conditions:**

- There are ideal ambient conditions for high-resolution counting
- The parts to be counted are not scattered

**** Smallest part weight for piece counting - under normal conditions:**

- There are unsteady ambient conditions (draft, vibrations)
- The parts to be counted are being scattered

2 Declaration of conformity


The current EC/EU Conformity declaration can be found online in:


www.kern-sohn.com/ce

3 Appliance overview

3.1 Components








Pos.	Designation	Pos.	Designation
1	Windshield	**7**	Rear Display
2	Weighing plate	**8**	Mains adapter connection
3	Levelling screw	**9**	Battery case
4	Bubble level	**10**	Transport lock
5	Keyboard	**11**	Adjustment switch
6	Display		

3.2 Operating elements





3.2.1 Keyboard overview

Button	Name	Function in Operating mode	Function in Menu
ESC	**ESC**	➢ Calculate weighing data via interface	➢ Exit menu / back to weighing mode ➢ Menu level back
MODE	**MODE**	➢ Switch weighing unit	➢ Navigation key ↓
PCS	**PCS**	➢ Counting, see chap. 12	➢ Navigation key ←
%	**%**	➢ Percent weighing, see chap. 11.4.2 ➢ Internal adjustment (press button long time)	➢ Navigation key →
TARE	**TARE**	➢ Taring	➢ Navigation key ↑
→0←	**ZERO**	➢ Zeroing	➢ Select menu item ➢ Confirm selection
ON/OFF	**ON/OFF**	➢ Switch on/off (press button long time) ➢ Switch on/off the display background illumination (press button short time)	

3.2.2 Numerical input

Button	Designation	Function
PCS ←	Navigation key ←	Select cipher
		Confirm entry. Press button repeatedly for every digit. Wait until the numeric input window extinguishes.
% →	Navigation key →	Select cipher
		Confirm entry. Press button repeatedly for every digit. Wait until the numeric input window extinguishes.
MODE ↓	Navigation key ↓	Reduce flashing cipher (0 – 9)
TARE ↑	Navigation key ↑	Increase flashing cipher (0 – 9)

3.2.3 Overview of displays

Main display	
Additional display	

Anzeige	Beschreibung
◣◢	Stability display
>0<	Zero display

▬	Minus display
HI OK LO	Tolerance marks for check weighing
0 F	Bar graph display Indicates how much the weighing plate is loaded with respect to the maximum weighing range
PTARE	PRE-Tare enabled
HOLD	Data-Hold enabled
NET	Display net weight value
G	Display gross weight value
∑	Weighing data can be found in the sum memory
AP	Autoprint enabled
Units display / Pcs/ %	options g or Application icon [**Pcs**] for piece counting or [%] for determination of percentage
No.1 ▼	Net weight value display active
No.2 ▼	Stability display active
No.3 ▼	Zero display active
No.4 ▼	Application icon [**Pcs**] for piece counting
No.5 ▼	[%] for percentage determination
No.6 ▼	Unit display g

4 Basic Information (General)

4.1 Proper use

The balance you purchased is intended to determine the weighing value of material to be weighed. It is intended to be used as a “non-automatic balance”, i.e. the material to be weighed is manually and carefully placed in the centre of the weighing plate. As soon as a stable weighing value is reached, the weighing value can be read.

4.2 Improper Use

- Our balances are non-automatic balances and not provided for use in dynamic weighing processes. However, the balances can also be used for dynamic weighing processes after verifying their individual operative range, and here especially the accuracy requirements of the application.
- Do not leave permanent load on the weighing plate. This may damage the measuring system.
- Impacts and overloading exceeding the stated maximum load (max) of the balance, minus a possibly existing tare load, must be strictly avoided. Balance may be damage by this.
- Never operate the balance in explosive environment. The serial version is not explosion protected.
- The structure of the balance may not be modified. This may lead to incorrect weighing results, safety-related faults and destruction of the balance.
- The balance may only be used according to the described conditions. Other areas of use must be released by KERN in writing.

4.3 Warranty

Warranty claims shall be voided in case:

- Our conditions in the operation manual are ignored
- The appliance is used beyond the described uses
- The appliance is modified or opened
- Mechanical damage or damage by media, liquids, natural wear and tear
- The appliance is improperly set up or incorrectly electrically connected
- The measuring system is overloaded

4.4 Monitoring of Test Resources

In the framework of quality assurance the measuring-related properties of the balance and, if applicable, the testing weight, must be checked regularly. The responsible user must define a suitable interval as well as type and scope of this test. Information is available on KERN's home page (www.kern-sohn.com) with regard to the monitoring of balance test substances and the test weights required for this. In KERN's accredited calibration laboratory test weights and balances may be calibrated (return to the national standard) fast and at moderate cost.

5 Basic Safety Precautions

5.1 Pay attention to the instructions in the Operation Manual



⇨ Carefully read this operation manual before setup and commissioning, even if you are already familiar with KERN balances.

5.1 Personnel training

The appliance may only be operated and maintained by trained staff.

6 Transport and storage

6.1 Testing upon acceptance

When receiving the appliance, please check packaging immediately, and the appliance itself when unpacking for possible visible damage.

6.1 Packaging / return transport



⇨ Keep all parts of the original packaging for a possibly required return.

⇨ Only use original packaging for returning.

⇨ Prior to dispatch disconnect all cables and remove loose/mobile parts.

⇨ Reattach possibly supplied transport securing devices.

⇨ Secure all parts such as the wind screen, the weighing plate, power supply unit etc. against shifting and damage.

7 Unpacking, Installation and Commissioning

7.1 Installation Site, Location of Use

The balances are designed in a way that reliable weighing results are achieved in common conditions of use.

You will work accurately and fast, if you select the right location for your balance.

On the installation site observe the following:

- Place the balance on a firm, level surface.
- Avoid extreme heat as well as temperature fluctuation caused by installing next to a radiator or in the direct sunlight.
- Protect the balance against direct draughts due to open windows and doors.
- Avoid jarring during weighing.
- Protect the balance against high humidity, vapours and dust.
- Do not expose the device to extreme dampness for longer periods of time. Non-permitted condensation (condensation of air humidity on the appliance) may occur if a cold appliance is taken to a considerably warmer environment. In this case, acclimatize the disconnected appliance for ca. 2 hours at room temperature.
- Avoid static charge of goods to be weighed or weighing container.
- Do not operate in areas with hazard of explosive material or in potentially explosive atmospheres due to materials such as gasses, steams, mists or dusts.
- Keep away chemicals (such as liquids or gasses), which could attack and damage the balance inside or from outside.
- In the event of the occurrence of electromagnetic fields, static charges (e.g., when weighing / counting plastic parts) and unstable power supply, large display deviations (incorrect weighing results, as well as damage to the scale) are possible. Change location or remove source of interference.

7.2 Unpacking and checking

Remove device and accessories from packaging, remove packaging material and install the device at the planned workplace. Check if that there has been no damage and that all items of delivery scope are present.

Scope of delivery / serial accessories:

- Balance
- Mains adapter
- Operating instructions
- Protective hood


7.3 Assembling, Installation and Levelling

⇨ Remove the transportation lock.

⇨ Install weighing plate and wind shield if necessary.

⇨ Ensure that the balance is installed in a level position.

⇨ Level balance with foot screws until the air bubble of the water balance is in the prescribed circle.



⇨ Check levelling regularly

7.4 Mains connection

Select a country-specific power plug and insert it in the mains adapter.

Check, whether the voltage acceptance on the scales is set correctly. Do not connect the scales to the power mains unless the information on the scales (sticker) matches the local mains voltage.

Only use KERN original mains adapter. Using other makes requires consent by KERN.


Important:

➢ Before starting your weighing balance, check the mains cable for damage.

➢ Ensure that the power unit does not come into contact with liquids.

➢ Ensure access to mains plug at all times.

7.5 Rechargeable battery operation (Factory option)

ATTENTION   	⇨ The rechargeable battery and the battery match with each other. Only use the delivered mains adapter. ⇨ Do not use the balance during the loading process. ⇨ The rechargeable battery can only be replaced by the same or by a type recommended by the manufacturer. ⇨ The rechargeable battery is not protected against all environmental influences. If the rechargeable battery is exposed to certain environmental influences, it may set on fire or explode. Persons may be injured or material damage may occur. ⇨ Protect the rechargeable battery against fire and heat. ⇨ Do not bring the rechargeable battery in contact with fluids, chemical substances or salt. ⇨ Do not expose the rechargeable battery to high pressure or microwaves. ⇨ Under no circumstances the rechargeable batteries and the charging unit may be modified or manipulated. ⇨ Do not use a defective, damaged or deformed rechargeable battery. ⇨ Do not connect or short-circuit the electrical contacts of the rechargeable battery with metallic objects. ⇨ Liquid may squirt out from a damaged rechargeable battery. If the liquid gets into contact with the skin or the eyes, the skin and the eyes may be irritated. ⇨ Ensure the correct polarity when inserting or changing the rechargeable battery (see instructions in the battery compartment) ⇨ The rechargeable battery operation is overridden when the mains adapter is connected. For weighing in mains operation > 48 hrs. the rechargeable batteries must be removed! (Danger of overheating). ⇨ If the rechargeable battery starts to smell, being hot, changing the colour or being deformed, it must be immediately unplugged from mains supply and from the balance if possible.

7.5.1 Load rechargeable battery

The rechargeable battery pack (Option) is charged using the mains cable supplied

Before the first use, the rechargeable battery package should be charged by connecting it to the mains power cable for at least 15 hours.

To save the rechargeable battery, in menu (see chap. 14.3.1) the automatic switch-off function < AUtoFF > can be activated.

If the capacity of the rechargeable batteries is exhausted, <Lo Bat> appears in the display. Connect the power cable as soon as possible to load the rechargeable battery. Charging time until complete recharging is approx. 6,5 hrs.

7.6 Connection of peripheral devices

Before connecting or disconnecting of additional devices (printer, PC) to the data interface, always disconnect the balance from the power supply.

With your balance, only use accessories and peripheral devices by KERN, as they are ideally tuned to your balance.

7.7 Initial Commissioning

In order to obtain exact results with the electronic balances, your balance must have reached the operating temperature (see warming up time chap. 1). During this warming up time the balance must be connected to the power supply (mains, rechargeable accumulator or battery).

The accuracy of the balance depends on the local acceleration of gravity.


Strictly observe hints in chapter Adjustment.

7.8 Adjustment

As the acceleration value due to gravity is not the same at every location on earth, each balance must be coordinated - in compliance with the underlying physical weighing principle - to the existing acceleration due to gravity at its place of location (only if the balance has not already been adjusted to the location in the factory). This adjustment process must be carried out for the first commissioning, after each change of location as well as in case of fluctuating environment temperature. To receive accurate measuring values it is also recommended to adjust the balance periodically in weighing operation.

- Carry out adjustment as near as possible to the balance's maximum weight (recommended adjustment weight see chap. 1). Weights of different nominal values or tolerance classes may be used for adjustment but are not optimal for technical measuring. The accuracy of the adjustment weight must correspond approximately to or, if possible, be better than, the readability **[d]** of the balance. Info about test weights can be found on the Internet at: http://www.kern-sohn.com
- Observe stable environmental conditions. A warm up time (see chapter 1) is required for stabilization.
- Ensure that there are no objects on the weighing plate.
- Avoid vibration and air flow.
- Always carry out adjustment with the standard weighing plate in place.

7.8.1 Internal adjustment < CAL int >



⇨ Press and hold the TARE and ON/OFF buttons simultaneously to enter the setup menu.

⇨ Wait until the first menu item < CAL > is displayed.

⇨ Confirm by **[↵]** button, < CAL int > will be displayed.

⇨ Confirm by pressing the **[↵]** button

⇨ Internal adjustment is being carried out (progress is visible via the bar graph display)

⇨ After successful adjustment the balance automatically returns to weighing mode.
In case of an adjustment error (e.g. objects on the weighing plate) the display will show the error message < ErrorG >. Switch off balance and repeat the adjustment process.

The %-button (press button long time, then confirm with the **[↵]** button) in the operating mode can also be used to perform the internal adjustment.

8 Verification

General:

According to EU directive 2014/31/EU balances must be officially verified if they are used as follows (legally controlled area):

- For commercial transactions if the price of goods is determined by weighing.
- For the production of medicines in pharmacies as well as for analyses in the medical and pharmaceutical laboratory.
- For official purposes
- For manufacturing final packages

In cases of doubt, please contact your local trade in standard.

Balances in the legally controlled area (-> verified balances) must keep the error limits in the verification validity period – normally they are the double of the verification error limits.
When this verification validity period expires, a re-verification must be carried out. Should be necessary an adjustment of the balance to keep the verification error limits to satisfy the reverification requirements, this is not deemed a warranty case.

Verification notes:

An EU type approval exists for balances described in their technical data as verifiable. If the balance is used where obligation to verify exists as described above, it must be verified and re-verified at regular intervals.


Re-verification of a balance is carried out according to the respective national regulations. The validity for verification of balances in Germany is e.g. 2 years.

The legal regulation of the country where the balance is used must be observed!

Verification of the balance is invalid without the seal.
The seal marks attached on balances with type approval point out that the balance may only be opened and serviced by trained and authorised specialist staff. If the seal mark is destroyed, verification looses its validity. Please observe all national laws and legal regulations. In Germany a re-verification will be necessary.

This scale is direct to sales approved.


Position of the official seals:



9 Basic Operation


9.1 Turn on/off

Start-up:




⇨ Press the **ON/OFF** button.
The display lights up and the balance carries out a selftest.
Wait until the weight display appears
The scales are now ready for operation using the last active application

Switching off:



⇨ Keep **ON/OFF** button pressed until the display disappears

9.2 Simple weighing



⇨ Check zero display [**>0<**] and set to zero with the help of the **ZERO** key, as required.

⇨ Place goods to be weighed on balance

⇨ Wait until the stability display appears (▬).

⇨ Read weighing result.


Overload warning
Overloading exceeding the stated maximum load (max) of the device, minus a possibly existing tare load, must be strictly avoided.
This could damage the instrument.
Exceeding the maximum load is indicated by the display "⌐ - - -¬". Unload balance or reduce preload.

9.3 Zeroing

In order to obtain optimal weighing results, reset to zero the balance before weighing.

Zeroing is only possible in the range ± 2% Max.

For values greater than ± 2% maximum the error message < OL in it> is displayed




⇨ Unload the balance

⇨ Press the **ZERO** key to set the balance to zero.

9.4 Taring

The dead weight of any weighing container may be tared away by pressing a button, so that the following weighing procedures show the net weight of the goods to be weighed.




⇨ Put weighing container on the weighing plate.

⇨ Wait until the stability display appears ◣◢), then press **TARE** key. The weight of the container is now internally saved. Zero display and indicator **<NET>** will appear. **<NET>** informs that all shown weight values are net values.

- When the balance is unloaded the saved taring value is displayed with negative sign.
- To delete the stored tare value, unload the weighing plate and press the **TARE** key or the **ZERO** key.

9.5 Switch-over weighing unit

Enable unit:




The unit for quick selection can be determined when the **[MODE]**-button is shortly pressed for the first time.

⇨ Press the **[MODE]**-button and wait until the display flashes.


⇨ Use the navigation keys ↓↑ to select the weighing unit and confirm on **[↵]**-button.

Switch over unit:



⇨ Using **[MODE]** button, it is possible to switch over between the enabled unit 1 and unit 2.

Enable another unit:



⇨ Select menu setting < unit > and confirm on **[↵]** button.

⇨ Wait until the display flashes.

⇨ Use the navigation keys ⇵ to select the weighing unit and confirm on **[↵]** button.


- For the required settings of an application unit (%) selection, please see chap. 11.4.2.
- This menu setting deactivates the set unit for quick selection.

10 Operating concept

From factory the balance is delivered with various applications (weighing, check weighing, counting). After the first start-up the balance is in the <Weighing> application.

In the **application menu** (see chap.14.2.) however, you can define, selecting an application, in which mode the balance after switching-on has to continue working. Either as per standard in weighing mode or e.g. in check mode or counting mode.

Selecting an application:




⇨ Press the **TARE** key and hold it until < APcNEn > is displayed.

⇨ The display changes to < WGhNodE> followed by <PtArE>.

⇨ Use the **TARE**-button to select the menu setting <NodE> and acknowledge with **[↵]** button.

⇨ The last active application, e.g. < WE ıh > is displayed.



⇨ Use the **TARE**-button to select the desired application, selectable

WEIGH Weighing

COUNT Counting

CHECK Check weighing

⇨ Acknowledge selection by **[↵]** button.

According to the selected application in the application menu just appear the application-specific settings, so that you reach the target quickly without deviation.

- Information about the application-specific settings you will find in the description of the respective application.
- All basic settings and parameters, which influence the whole operation of the balance, are resumed in the **Setup Menu** (see chap.14.3)
  These settings remain valid for all applications.
- The number of the available applications depends on the model.

Change application:

⇨ Press the **TARE** button and keep it pressed until the first menu item of the application menu will be displayed

⇨ Use the 🡻 button to select the menu setting < MODE > and acknowledge with **[↵]** button. The current setting will be displayed.

⇨ Press the 🡻 button to select the required unit and confirm by pressing the **[↵]** button.

11 Application <Weighing>

How to carry out a simple weighing and taring, please refer to chap. 9.2 or 9.4. Further specific settings you will find in the following chapters.

Shouldn't the application <Weighing> already be enabled, select the menu setting < ModE > ➡ < WE ih >, see chap. 10.

11.1 Application-specific settings

Call up menu:

⇨ Press the **TARE** key and hold it until < APcNEn> is displayed.

⇨ The display changes to < WChNod> followed by < PtArE>.

⇨ Navigation in menu see chap. 14.1


Overview (verifiable models):

Level 1	Level 2	Level 3	Description / Chapter
PtArE PRE-TARE	ActuAL	Take over the placed weight as PRE-TARE value,, see chap. 11.2.1	
	MAnuAL	Numerical input of the tare weight, see chap. 11.2.2	
	cLEAr	Delete PRE-TARE value	
hoLd	-	Start-Hold function, see chap. 11.3	
un it Units	g	This function defines in which weighing unit the result will be displayed, see chap. 11.4.1	
ModE Applications	WE ih	Weighing	see chap. 10
	count	Counting	
	chEcK	Check weighing	

11.2 PRE-Tare

11.2.1 Take over the placed weight as PRE-TARE value

< PtArE > ➡ < ActuAL >



⇨ Deposit weighing container

⇨ Invoke menu setting < PtArE > and confirm by **[↵]** button.

⇨ To take over the placed weight as a PRE-TARE value, use the navigation keys ↓↑ to select < ActuAL >

⇨ Acknowledge by **[↵]** button. < WAit > is displayed.

⇨ The weight of the weighing container is stored as tare weight. Zero display and indicators **<PTARE>** and **<NET>** will appear.

⇨ Remove the weighing container, the tare weight will appear with negative sign.

⇨ Place the filled weighing container.


⇨ Wait until the stability display appears (▬).

⇨ Read net weight.

The entered tare weight remains valid until a new tare weight is input. To delete press the TARE key or confirm the menu setting < CLEAr > using the **[↵]** button.

11.2.2 Enter the known tare weight numerically

< PtArE > ➡ < nAnuAL >



⇨ Invoke menu setting < PtArE > and confirm by **[↵]** button.

⇨ Using the navigation keys ⇵ select the setting
Select < nAnuAL > and confirm by pressing the **[↵]** button.

⇨ Enter known tare weight, numerical input
see chap. 3.2.2, the active digit flashes.

⇨ The input weight is saved as tare weight, the indicators **< PTARE >** and **< NET >** and the tare weight with minus sign will appear.


⇨ Place the filled weighing container.

⇨ Wait until the stability display appears (▬).

⇨ Read net weight.

i The entered tare weight remains valid until a new tare weight is input. To delete enter the zero value or confirm the menu setting < cLEAr > using the **[↵]** button.

11.3 Data-Hold function



⇨ Menu setting < hoLd >


⇨ Place goods to be weighed.

⇨ Acknowledge by **[↵]** button.

⇨ The first stable weight value is symbolised by [HOLD] in the upper edge of the display. After the load is removed, the value is left in the display for another 10 seconds.

11.4 Weighing Units

11.4.1 Setting weighing unit




⇨ Select menu setting < un it> and confirm on **[↵]** button.

⇨ Wait until the display flashes.


⇨ Use the navigation keys ⇵ to select the weighing unit and confirm on **[↵]** button.

- For the required settings of an application unit (%) selection, please see chap. 11.4.2.
- Using the **[MODE]** button you can switch between the active unit 1 and unit 2.



11.4.2 Percent weighing by application unit <%>

The application unit <%> allows to check the weight of a sample in percent, based on a reference weight.



⇨ Select menu setting < unit >.

⇨ Place a reference weight which corresponds to 100 %

⇨ Acknowledge by **[↵]** button.

⇨ Use the navigation keys ↓↑ to select the setting < % > and confirm on **[↵]** button.

⇨ From now on the weight of the sample will be shown in percent based on the reference weight

12 Application <Counting>

Shouldn't the application <Counting> already be enabled, select the menu setting < nodE > ➡ < count >, see chap. 10

12.1 Application-specific settings

Call up menu:

⇨ Press the **TARE** key and hold it until < APcnEn> is displayed.

⇨ The display changes to < counod > followed by < rEF >.

⇨ Navigation in menu see chap. 14.1

Overview:

Level 1	Level 2	Level 3	Description / Chapter
rEF Reference quantity	5	Reference quantity 5	
	10	Reference quantity 10	
	20	Reference quantity 20	
	50	Reference quantity 50	
	FrEE	Optional, numerical input, see chap. 3.2.2	
	inPut	Input of piece weight, numerical input, see chap. 3.2.2	
PtArE PRE-TARE	ActuAL	Take over the placed weight as PRE-TARE value, see chap.11.2.1	
	nAnuAL	Numerical input of the tare weight, see chap. 11.2.2	
	cLEAr	Delete PRE-TARE value	
tArGEt Target counting	UALuE	Target quantity	see chap. 12.2.2
	ErruPP	Upper tolerance	
	ErrLoW	Lower tolerance	
	cLEAr	Delete settings	
nodE Applications	count	Counting	see chap. 10
	chEcK	Check weighing	
	WE ih	Weighing	

12.2 Using the application


12.2.1 Piece counting

Before the balance can count parts, it must know the average part weight (i.e. reference). Proceed by putting on a certain number of the parts to be counted. The balance determines the total weight and divides it by the number of parts, the so-called reference quantity. Counting is then carried out on the basis of the calculated average piece weight.

- The higher the reference quantity the higher the counting exactness.
- Especially high reference must be selected for small parts or parts with considerably different sizes.
- Smallest counting weight see table „Technical data“.

1. Set reference

Reference quantity 5, 10, 20 or 50:



⇨ If necessary, put on and tare the weighing container.

⇨ Put on the desired quantity of reference pieces.


⇨ Invoke menu setting < rEF > and confirm by **[↵]** button.

⇨ Use the navigation keys ↓↑ to select the reference piece quantity (5, 10, 20, 50) according to the placed reference and confirm with the **[↵]** button.

⇨ The balance will calculate the average item weight and then displays the quantity of pieces.

⇨ Remove reference weight. The balance is now in piece counting mode counting all units on the weighing plate.

Reference quantity user-defined:



⇨ If necessary, put on and tare the weighing container.

⇨ Put on the desired quantity of reference pieces.

⇨ Invoke menu setting < ref > and confirm by **[↵]** button.

⇨ Use the navigation keys ↓↑ to select the setting < FrEE> and confirm on **[↵]** button.


⇨ The numeric input window appears.

⇨ Enter and confirm the quantity of the placed reference parts, numerical input see chap. 3.2.2

⇨ The balance will calculate the average item weight and then displays the quantity of parts.

⇨ Remove reference weight. The balance is now in piece counting mode counting all units on the weighing plate.


Counting with optional piece weight:



⇨ Invoke menu setting < rEF > and confirm on **[↵]** button.

⇨ Use the navigation keys ↓↑ to select the setting < inPut > and confirm on **[↵]** button.

⇨ Use the navigation keys ↓↑ to select the weighing unit and confirm on **[↵]** button.




⇨ Use the navigation keys ⇃↾ to select the comma position and confirm on **[↵]** button.

⇨ Enter piece weight, numerical input
see chap. 3.2.2, the active digit flashes.

⇨ Acknowledge by **[↵]** button.

The balance is now in piece counting mode counting all units on the weighing plate.

2. Parts counting



⇨ If necessary, put on and tare the weighing container.

⇨ Fill the counting quantity. The piece quantity is shown directly in the display.

12.2.2 Target counting

The <Target counting> application variant allows weighing of goods within set tolerance limits in keeping with a determined target quantity.

Reaching the target quantity is indicated by an acoustic (if activated in menu) and an optic signal (tolerance marks).

Optical signal:

The tolerance marks provide the following information:


HI	Target quantity exceeds defined tolerance
OK	Target quantity within defined tolerance
LO	Target quantity below defined tolerance

Acoustic signal:

The acoustic signal depends on the menu setting
< SEtuP ➡ bEEPEr >, see chap. 14.3.1.

Procedure:

1. Define target quantity and tolerances



⇨ Make sure that the scale is in counting mode and that an average piece weight has been defined (see chap. 12.2.1).

⇨ Use the navigation keys ↓↑ to select the setting < tArGEt > and confirm with **[↵]** button.

< UALuE > is displayed.

⇨ Confirm on **[↵]** button, the numeric input window appears. The active digit is flashing.

⇨ Enter the target quantity (numerical input see chap. 3.2.2) and confirm the entry.


The balance returns to the < UALuE > menu.

⇨ Use the navigation keys ↓↑ to select the setting < ErruPP> and confirm on **[↵]** button.


⇨ Use the navigation keys ↓↑ to select the weighing unit and confirm on **[↵]** button.

⇨ The numeric input window appears. The active digit is flashing.

⇨ Enter the upper tolerance (for numerical input see chap. 3.2.2) and confirm the entry.





The balance returns to the < ErruPP > menu.



⇨ Use the navigation keys ↓↑ to select the setting < ErrLoH> and confirm on **[↵]** button.


⇨ Use the navigation keys ↓↑ to select the weighing unit and confirm on **[↵]** button.






⇨ The numeric input window appears. The active digit is flashing.

⇨ Enter the lower tolerance (for numerical input, see chap. 3.2.2) and confirm the entry.



⇨ The balance returns to the < ErrLoH > menu.






⇨ Press repeatedly **ESC**-button to exit menu.

Finished the setting works, the weighing balance will be ready for target counting.

2. Start tolerance check:

⇨ Determine the average piece weight, see chap. 12.2.1

⇨ Place the weighed material and check by means of the tolerance marks / acoustic signal if the weighed material is within the defined tolerance.

Load below specified tolerance	Load within specified tolerance	Load exceeds specified tolerance
		

The entered values will remain valid until new values are entered.

To delete the values, select menu setting < tARGEt > ➡ < cLEAr > and confirm on **[↵]** button.

13 Application < Checkweighing >

Shouldn't the application <Checkweighing> already be enabled, select the menu setting < MODE > ➡ < CHECK >, see chap. 10

13.1 Application-specific settings

Call up menu:

⇨ Press the **TARE** key and hold it until < APPMEN > is displayed.

⇨ The display changes to < CHANGE> followed by < TARGET >.

⇨ Navigation in menu see chap. 14.1

Overview:

Level 1	Level 2	Level 3	Description / Chapter
TARGET Target weighing, see chap. 13.2.1	VALUE	Target weight, numerical input, see chap. 3.2.2	
	ERRUPP	Upper tolerance, numerical input see chap. 3.2.2	
	ERRLOW	Lower tolerance, numerical input see chap. 3.2.2	
	CLEAR	Delete settings	
LIMITS check weighing, see chap. 13.2.2	LIMUPP	Upper limit value, numerical input see chap. 3.2.2	
	LIMLOW	Lower limit value, numerical input see chap. 3.2.2	
	CLEAR	Delete settings	
PTARE PRE-TARE	ACTUAL	Take over the placed weight as PRE-TARE value, see chap.11.2.1	
	MANUAL	Numerical input of the tare weight, see chap. 11.2.2	
	CLEAR	Delete PRE-TARE value	
MODE Applications	WEIGH	Weighing	see chap. 10
	COUNT	Counting	
	CHECK	Check weighing	

13.2 Using the application

13.2.1 Target weighing

The <target weighing> application variant allows weighing of goods within set tolerance limits in keeping with a determined target weight.

Reaching the target weight is indicated by an acoustic (if activated in menu) and an optic signal (tolerance marks).

Optic signal:

The tolerance marks provide the following information:


HI	Upper limit
OK	Target weight
LO	Lower limit

Acoustic signal:

The acoustic signal depends on the menu setting
< SEtuP ➡ bEEPEr >, see chap. 14.3.1.

Procedure:

1. Define target weight and tolerances



⇨ Use the navigation keys ⇵ to select the setting < tArGEt > and confirm with **[↵]** button.

< UALuE > is displayed.

⇨ Confirm on **[↵]** button, the numeric input window appears. The active digit is flashing.

⇨ Enter target weight (numerical input see chap. 3.2.2) and confirm the entry.

The balance returns to the < UALuE > menu.


⇨ Use the navigation keys ⇵ to select the setting < ErruPP> and confirm on **[↵]** button.

⇨ Use the navigation keys ⇵ to select the weighing unit and confirm on **[↵]** button.

⇨ The numeric input window appears. The active digit is flashing.


⇨ Enter the upper limit for the weight deviation (numerical input see chap. 3.2.2) and confirm the entry.

The balance returns to the <ErruPP> menu.



⇨ Use the navigation keys ⇃↾ to select the setting < Err-LoW> and confirm on **[↵]** button.


⇨ Use the navigation keys ⇃↾ to select the weighing unit and confirm on **[↵]** button.



⇨ The numeric input window appears. The active digit is flashing.

⇨ Enter lower limit for weight deviation (numerical input see chap. 3.2.2) and confirm the entry.

⇨ The balance returns to the < ErrLoW> menu.






⇨ Press repeatedly **ESC-**button to exit menu.

Finished the setting works, the weighing balance will be ready for checkweighing.

3. Start tolerance check:

⇨ Place the weighed material and check by means of the tolerance marks / acoustic signal if the weighed material is within the defined tolerance.

Load below specified tolerance	Load within specified tolerance	Load exceeds specified tolerance
		

The entered values will remain valid until new values are entered.

To delete the values, select menu setting < tARGEt > ➡ < cLEAr > and confirm on **[↵]** button.

13.2.2 Checkweighing

With the <Checkweighing> application variant you can check if the weighing good is within a predefined tolerance range.

When limit values are exceeded below or above, an acoustic signal (if enabled in menu) will sound and an optic signal (tolerance marks) will be displayed

Optic signal:

The tolerance marks provide the following information:


HI	Weighed-in goods exceed predefined tolerance
OK	Weighed-in goods within predefined tolerance
LO	Weighed-in goods below predefined tolerance

Acoustic signal:

The acoustic signal depends on the menu setting
< SEtuP > ➡ < bEEPEr >, see chap. 14.3.1.

Procedure:

1. Define limit values



⇨ Using the navigation keys ⇵ select the setting


Select < LiMits> and confirm on **[↵]** button.

< LiMuPP > will appear.

⇨ Press **[↵]** button to confirm, the numeric input window for entering the upper limit value will appear.
The active digit is flashing.

⇨ Enter upper limit value (numerical input see chap. 3.2.2) and confirm the entry.

The balance returns to the < LiMuPP > menu.



⇨ Use the navigation keys ⇵ to select setting < L inLoH >.

⇨ Press **[↵]** button to confirm, the numeric input window for entering the lower limit value will appear. The active digit is flashing.

⇨ Enter lower limit value (numerical input see chap. 3.2.2) and confirm the entry.




The balance returns to the < L inLoH> menu.

⇨ Press repeatedly **ESC-**button to exit menu.

Finished the setting works, the weighing balance will be ready for checkweighing.

2. Start tolerance check:

⇨ Place the weighed material and check by means of the tolerance marks / acoustic signal if the weighed material is within the defined tolerance.

Load below specified tolerance	Load within specified tolerance	Load exceeds specified tolerance
		


The entered values will remain valid until new values are entered.

To delete the values, select menu setting < L in tS > ➡ < CLEAr > and confirm on **[↵]** button.

14 Menü

14.1 Navigation in the menu

Call up menu:

Application menu	Setup menu
	
Press the **TARE** button and keep it pressed until the first menu item will be displayed	Press the **TARE** and **ON/OFF** button at the same time and keep them pressed until the first menu item will be displayed

Select and adjust parameters:

Scrolling on one level	Use the navigation buttons to select the individual menu blocks one by one. Use the navigation key 🡻 to scroll down. Use the navigation key 🡹 to scroll up.
Activate menu item / **Confirm selection**	Press **[↵]** key
Menu level back / back to weighing mode	Press **ESC-**key

14.2 Application menu

The application menu allows you a fast and targeted access to the respectively selected application (see chap. 10).

An overview of the application-specific settings you will find in the description of the respective application.

14.3 Setup menu

In the setup menu you have the possibility to adapt the behaviour of the balance to your requirements (e.g. environmental conditions, especial weighing processes).

These settings are global and do not depend on the selected application.

14.3.1 Overview < setup >

Verifiable models:

Level 1	Level 2	other levels / description		
		Description		
CAL Adjustment	CAL int	➔ Internal adjustment, see chap. 7.8.1		
bEEPEr Acoustic signal	KEYb	oFF	Switch on / off acoustic signal by pressing button	
		on		
	ChECK	ch-oK	oFF	Acoustic signal off
			SLOW	Slow
			Std	Standard
			FASt	Fast
			cont.	Continuous
		ch-Lo	oFF	Acoustic signal off
			SLOW	Slow
			Std	Standard
			FASt	Fast
			cont.	Continuous
		ch-hi	oFF	Acoustic signal off
			SLOW	Slow
			Std	Standard
			FASt	Fast
			cont.	Continuous
AutoFF Automatic switch-off function in rechargeable battery operation	ModE	oFF	Automatic switch-off function switched off	
		Auto	The balance is automatically switched-off according to the time without load change or without operation defined in menu item < t iME >	
		onLY0	Automatic switch-off only with zero display	
	t iME	30 S	After the set time without load change or operation the balance will switch off automatically	
		1 0 in		
		2 0 in		
		5 0 in		
		30 0 in		
		60 0 in		

bL iGhE Display background illumination	nodE	ALWAYS	Background lighting of display is switched on permanently
		t iMEr	The background illumination is automatically switched-off according to the time without load change or without operation defined in menu item < t iME >
		nobL	Display background illumination always switched off
	t iME	5 S 10 S 30 S 1 0 in 2 0 in 5 0 in 30 0 in	Definition, after which time the background illumination is automatically switched-off without load change or without operation.
	oFF	i	In the event that small quantities are removed or added to the material to be weighed, incorrect weighing results can be displayed due to the “stability compensation“. (e.g. slow flow of liquids from a container placed on the balance, evaporating processes). When apportioning involves small variations of weight, it is advisable to switch off this function.
nodE Weighing applications	WE ih	Weighing	
	count	Counting	
	chEcK	Check weighing	
inFo	nodEL	Model name of the balance	
	SEr iAL	Serial number of the balance	
	SWUEr	Software version of the balance	
	bAL id	on	When set to “Off”, the BAL ID is not printed when the GLP layout is activated. When set to “On”, the user can enter a 7-digit number. This number is printed when the GLP layout is selected. The number is saved even if the user sets the BAL ID back to “Off”.
		oFF	
rESEt	Reset balance settings to factory settings		

15 Servicing, maintenance, disposal



Before any maintenance, cleaning and repair work disconnect the appliance from the operating voltage.

15.1 Cleaning

Please do not use aggressive cleaning agents (solvents or similar agents), but a cloth dampened with mild soap suds. Ensure that no liquid penetrates into the device. Polish with a dry soft cloth.

Loose residue sample/powder can be removed carefully with a brush or manual vacuum cleaner.

Spilled weighing goods must be removed immediately.

15.2 Servicing, maintenance

⇨ The appliance may only be opened by trained service technicians who are authorized by KERN.

⇨ Before opening, disconnect from power supply.

15.3 Disposal

Disposal of packaging and appliance must be carried out by operator according to valid national or regional law of the location where the appliance is used.

16 Instant help for troubleshooting

In case of an error in the program process, briefly turn off the balance and disconnect from power supply. The weighing process must then be restarted from the beginning.

Fault	Possible cause
The weight display does not glow.	• The balance is not switched on. • The mains supply connection has been interrupted (mains cable not plugged in/faulty). • Power supply interrupted.
The displayed weight is permanently changing	• Draught/air movement • Table/floor vibrations • Weighing plate has contact with foreign objects. • Electromagnetic fields / static charging (choose different location/switch off interfering device if possible)
The weighing result is obviously incorrect	• The display of the balance is not at zero • Adjustment is no longer correct. • The balance is on an uneven surface. • Great fluctuations in temperature. • Warm-up time was ignored. • Electromagnetic fields / static charging (choose different location/switch off interfering device if possible)

17 Error messages

Error message	Explication
CL in it	Zero setting range exceeded
undEr2	Zero setting range not achieved
instAb	Load instable
Wrong	Adjustment error
L_ _ _ J	Underload
⌜ - - - ⌝	Overload
LobAt	Capacity of batteries / rechargeable batteries exhausted